

MADE WITH MAGIC USER MANUAL

Ear Hat Revision 3

This magical item will excite, delight, light up and interact with select Disney experiences!

Visit <http://disneyparks.com/MadeWithMagic> for more details.

EXPERIENCE MODE

Ears will synchronize colors and patterns with select Disney Parks experiences such as nighttime spectacles.

These ears can also interact with select Disney mobile applications.

Experiences will take priority over the Made with Magic Wand.

EAR-TO-EAR MODE

Ears that are not near an experience will randomly change color and patterns, and ears that are near each other will synchronize!

The Made with Magic wand can change the color of the ears when in idle mode.

Both IDLE and SYNC mode work at home or anywhere outside of a Made with Magic experience.

CHANGING THE BATTERY

Have an adult loosen screw with screwdriver (not included) and lift up the battery cover.

Insert 2 x 1.5V AAA (R03) Batteries (included), following the indicated polarity (+ and -).

Have an adult replace battery cover and secure it with the screw.

Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries.

Caution: Remove tag and all plastic fasteners before giving to children.

Please retain this information for future reference.

FCC COMPLIANCE INFORMATION

FCC ID: Q3E-MWM-EH3

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by Disney could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.